



ATT200 series volume attenuators



PA Volume Controls - attenuators

- Attenuation in 10 steps (from 0dB to -33dB, position 0 is OFF)
- Audio transformer for 100V line installations
- White plastic front panel and knob (WS)
- Flush mounting or surface mounting with housing ATT-200 (back box)

ATT210P - 10w RMS @ 100v line

ATT225P - 25w RMS @ 100v line

ATT235P - 35w RMS @ 100v line

ATT250P - 50w RMS @ 100v line

soundservices.co.uk

Sound Services, 43 Albany Road, Fleet, Hants, GU51 3PU, UK

phone: 01252 620227

fax: 01252 627505

email: sales@soundservices.co.uk

www.soundservices.co.uk

www.soundservices.org.uk

VAT: 479 7742 77

100v Line Attenuators

100v line volume attenuators MUST be wired correctly - the 'in' terminal is the hot from the amplifier (usually the brown cable) with the terminal adjacent marked with an arrow the return to the amplifier (usually the blue cable). The 'out' terminal is the 'hot' to the 100v line loudspeaker (usually the brown cable) with the terminal adjacent marked with an arrow the return to the loudspeaker (usually the blue cable). For most purposes you should ignore the + & - 24v connections (if fitted). Do not exceed the rated power of the attenuator.